The chart below, assembled through 4 decades of putting thousands of parachutes in dozens of different aircraft, is intended to provide general guidance.

There are other important factors to consider when making this choice: height, weight, cockpit space restrictions (e.g. headroom), and the field elevations over which you fly.

Strong has a long history of helping Pilot's achieve a solution that works for them and their aircraft. Call us to discuss your specific needs in more detail.

MODEL / CONFIGURATION	303 "ACRO PRO" (BACK)	304 "BACK" (BACK)	305 "SEAT" (SEAT)	306 "X-COUNTRY" (BACK/CHAIR)	307 "SQDN SEAT" (SEAT)	311 "SUKHOI" (BACK)	314 "WEDGE" (BACK)	"RV-4 SEAT" (SEAT)	I-39 "CHAIR" (BACK/CHAIR)	NOTES
CANOPY COMPATIBILITY	1, 2	1, 2, 3	1, 2, 3	1, 2, 3	1, 2, 3	1, 2	1, 2	1, 2	3	1 - Compatible w/26 FT Mid-Lite
										2 - Compatible w/ Lo-Po Lite
										3 - Compatible w/ 30 FT Conical
ACRO SZD59	✓	✓								
ACRODUSTER			✓	`						4 - With Travel Cushion
ACROSPORT		✓	✓			✓				5 - Modified
APPLE BAY ZUNI		✓				✓				6 - With 2" Travel Cushion
ASW 25 & 27		✓								7 - Purposely built for this aircraft
BD-5 MICROJET				✓, 8						8 - Requires cockpit measurements
BERKUT				✓						
BOWERS FLYBABY			✓							
BUCKER JUNGMANN			✓							
CAP 10		✓		✓		✓				
CAP 231 & 232						✓				
CHRISTEN EAGLE		✓				✓				
CHRISTEN EAGLE II			✓			✓				
CESSNA AEROBAT & 152	✓	✓				✓				
CESSNA 172, 182, 205, 206, 207	✓	✓				✓				
CITABRIA			✓			✓				
CJ-6					✓					
CORSAIR					✓					
CURTISS-WRIGHT MODEL 19			✓							
DECATHLON			✓			✓				
DISCUS		✓								
DR 109			✓							
DUO DISCUS	✓	✓								
EXTRA 200, 230				✓						
EXTRA 300, 300L, 300S (REAR)				✓						
EXTRA 300, 300L, 300S (FRONT)	✓	✓								
F1 ROCKET	✓					✓				
FIRE BOLT			✓							
FOCKEWOLFE					✓					
FOUGA JET			✓, 4							
GILES 200, 202				✓						
GLASAIR					✓, 5					
GREAT LAKES		✓								
GROBE 103				✓						
GRUMMAN WARBIRDS					✓					
HARMON ROCKET						✓				
L-19 & L-29					✓					
L-39 ALBATROS									✓, 7	
LS8	✓	✓								
LANCAIR		✓								
LIBERTY XL-2	✓									
MXS, MX2	✓									
N3N					✓					
ONE DESIGN AKA JAC 1				✓						
P-51 MUSTANG					✓					
P-47				✓						
PI 49D FOCKE-W306					✓					
PITTS MODEL 12			✓			✓				
PITTS S1 & S1 C			✓			✓				
PITTS S2B (REAR)						✓				
PITTS S2B (FRONT)			✓							
PITTS SPECIAL			✓			✓				
PT-13					✓					
PT-19					✓					
PW-5		✓								
RV-3	✓		✓							
RV-4 (REAR)	✓						✓			
RV-4 (FRONT)								✓		

MODEL	303 "ACRO PRO" (BACK)	304 "BACK" (BACK)	305 "SEAT" (SEAT)	"X-COUNTRY" (BACK/CHAIR)	306 "SQDN SEAT" (SEAT)	307 "SUKHOI" (BACK)	311 "WEDGE" (BACK)	314 "RV-4 SEAT" (SEAT)	I-39 "CHAIR" (BACK/CHAIR)	NOTES
RV-6	✓						✓			
RV-6A	✓	✓								
RV-8 (REAR)	✓						✓			
RV-8 (FRONT)								✓		
RYAN PT-22			✓, 6							
SCOUT			✓							
SKYBOLT			✓							
SKYRAIDER			✓							
SNJ					✓					

MODEL	303 "ACRO PRO" (BACK)	304 "BACK" (BACK)	305 "SEAT" (SEAT)	"X-COUNTRY" (BACK/CHAIR)	306 "SQDN SEAT" (SEAT)	307 "SUKHOI" (BACK)	311 "WEDGE" (BACK)	314 "RV-4 SEAT" (SEAT)	I-39 "CHAIR" (BACK/CHAIR)	NOTES
SPITFIRE					✓					
STARDUSTER		✓								
STAUDACHER 3 300, 600, 900				✓						
STEARMAN (BUCKET SEAT)					✓					
STEARMAN (FLAT SEAT)				✓						
STEMME		✓		✓						
STEWART S-51										
SUKHOI SU-26						✓, 7				
SUKHOI SU-29, SU-31	✓	✓								
SUPER BLANIK	✓	✓								
T-28					✓		✓			
T-6					✓					
T-34 A or B					✓					
TBM AVENGER					✓					
TS11 ISKRA			✓							
VELOX REVOLUTION		✓					✓			
VENTUS 2CM				✓						
VULTEE BT-13					✓					
WACO			✓							
XAMANGO SUPER										
YAK 11 & 18A			✓, 4							
YAK 3 & 50			✓							
YAK 52, 54, 55			✓, 4							
ZIVKO EDGE	✓	✓								
ZLIN 50		✓								